



IQVideo

Lecture Capture System

LCS910

—User Manual—



 Returnstar Interactive Technology Group Co., Ltd.

Contents

1. Major Package List (Standard).....	3
2. Installation.....	3
3. Live Streaming.....	3
4. Director View Control.....	6
5. Recording Settings.....	7
6. DIY Lecture:.....	8
7. Station Operation Guidance.....	10

1. Major Package List (Standard)


Name	Amount
15.6 inch Station	1
Station Power Adaptor&Cable	1
PTZ Camera	2 (3、4 optional)
Camera Antenna	4
Station WIFI Antenna	2
Station RF Antenna	2
Camera Remote	2
Camera Power Adaptor&Cable	2
Camera Tripod	2
Microphone(1 receive、1 Sender)	1

2. Installation

- [1] Set the camera tripod and install the camera over the tripod.
- [2] Connect 2 Camera antenna with Camera,power on cameras.
- [3] Station install 2 WIFI Antenna and 2 RF Antenna.
- [4] Power on station and camera views would be auto-fetched.
- [5] Connect microphone receiver with station by the Mic in port.
- [6] Power on both microphone receiver and sender,after blue light stop flashing, pair finished.

3. Live Streaming.

1. The PC should be under one network segment with the station.(connect with the same router.)
- 2.Log in WEB of the Station using the station IP address.(browser by Chrome)
 - User: admin**
 - Password: admin**
3. Setting -> Live -> Channel Film1 Format (RTMP Push) -> Server Address (eg: <rtmp://110.90.11.185:21935/live/av12>) -> Live Enable(on) ->OK



Record

Live

Broadcast

IP

System

Version

Project

		09:00:00	09:45:00	00:45:00	<input checked="" type="checkbox"/>
		09:00:00	10:45:00	00:45:00	<input checked="" type="checkbox"/>
Timed Living		11:00:00	11:45:00	00:45:00	<input checked="" type="checkbox"/>
		13:00:00	13:45:00	00:45:00	<input checked="" type="checkbox"/>
		14:00:00	14:45:00	00:45:00	<input checked="" type="checkbox"/>
		15:00:00	15:45:00	00:45:00	<input checked="" type="checkbox"/>
		16:00:00	16:45:00	00:45:00	<input checked="" type="checkbox"/>

OK

4. Click Start(LIVE) by the WEB

Reboot ShutDown LogOut

Main Document Settings

Status

Topic Null

Speak Null

RecParam 1024*1080@25fps, 4096Kbps

LiveParam 1024*1080@25fps, 512Kbps

DiskSize 927.83GB/931.27GB

NetState Wired Network/Connected(WAN)

STORAGE Null Connected

SysTime 2023-02-17 17:57:30

REC 09:00:00

Start Pause Stop

LIVE 09:00:00

Start Stop

Subtitle S12

Logo S12

Title S12

Trailer S12

OSD Closing

Director Mode

Auto

PTZ

Speed

Presets

Layout

Transition


Computer Teacher Student 1 Student 2

Or click Start(LIVE) by the Station:


Login the Station:

User: admin

Password: admin




Menu->Set:



Advance:


User: admin

Password: admin




Live:

Change the Live Server address.




Click Live:




4. Director View Control.

8 Layout types to choose:



Drag by mouse directly, if you want to change the view or change the view position.



Or you could change the layout by the station:


1. Choose the layout.
2. Choose the Channel.
3. Click OK.



5. Recording Settings

Support File Name DIY. Format:MP4/TS.

Support changing : Resolution、BitRate、FrameRate、Code.




Support :Auto Recording after start.

Support :Set a video segment : 10 minutes,15 minutes,30minutes and so on.

(Reach time segment,generate a file and stop recording.)

Support :Set a Max video duration.(Reach record max duration,generate a file and stop recording)


Support :Select the recording schedule: Everyday or every Monday,every Tuesday etc.



6. DIY Lecture:


Subtitle:

- ◆ Customize 5 subtitle preset.
- ◆ Customize font、size、 color of the subtitle.




LOGO :

- ◆ Customize 5 logo presets.
- ◆ Customize your own logo file.
- ◆ Customize logo position.




Beginning and Ending pictures:

- ◆ Customize 5 Beginning and Ending presets.
- ◆ Customize Beginning and Ending file.
- ◆ Customize Beginning and Ending duration.




Date and Time:

- ◆ Customize your time format.
- ◆ Customize the color.



7. Station Operation Guidance

1. Start Recording & Stop Recording & Pause Recording.
2. Start Live Streaming & Stop Live Streaming.




3. Director-Manual-Layout:(Change Views)

Click the channel you want to change and choose the right channel you need, then click “OK”.




4. Change Station Language:

Go to Manu-Setting-Device set




5. Check Recorded Files:


Menu-Files:




6. Schedule Power:




7. Lock Screen Setting:



8. Time Format:



9. Record Strategy: Delete Priority or Stop Priority.



10. Network Information:

The image shows a network configuration interface with a dark theme. On the left is a vertical sidebar with buttons: "Device set", "Storage set", "Network set" (highlighted in green), "Version", "Advance", and "Exit". At the top right of the main area are "Config" (highlighted in green) and "Net Detect" buttons. The main area contains the following settings:

- DHCP:
- IP Address:
- Subnet Mask:
- Default Gateway:
- DNS Server:

At the bottom, there is an "OK" button (highlighted in green) and a circular "IQ" logo.



STOCK CODE
836453



 Returnstar Interactive Technology Group CO., LTD.
 6th Bldg. High-Tech Base. Fuzhou Fujian Prov. China
 0086-591-38202660
 0086-591-38203003
 www.IQBoard.net
 IQBoard@IQBoard.net